

# UltraEasy Composite Fence Installation Guide (Inground Installation)

v2 NL\_EN



# **CONTENTS**

<b>Important Note</b>	<b>3 - 4</b>
<b>Framing Layout for the UltraEasy Composite Fence</b>	<b>5</b>
<b>Exploded View of UltraEasy Fence</b>	<b>6</b>
<b>Parts List</b>	<b>7</b>
<b>Installation Procedure</b>	
-Post Installation	
-Fence Board Installation	<b>8 - 11</b>
	<b>11 - 16</b>



**IMPORTANT:**  
**Read All Sections Before You Start**

For the most up-to-date information, please visit our website @ [www.newtechwood.nl](http://www.newtechwood.nl)

Prior to installing any composite product, it is recommended that you check with local building codes for any special requirements or restrictions. The diagrams and instructions outlined in this guide are for illustration purposes only and are not meant or implied to replace a licensed professional. Any construction or use of NewTechWood must be in accordance with all local zoning and/or building codes. The consumer assumes all risks and liability associated with the construction and use of this product.

## Safety

When dealing with any type of construction project, it is necessary to wear appropriate safety equipment to avoid any risk of injuries. NewTechWood recommends but is not limited to the following safety equipment when handling, cutting, and installing NewTechWood: gloves, a respiratory protection, long sleeves, pants, and safety glasses.

## Tools

Standard woodworking tools may be used. It is recommended that all blades have a carbide tip. Standard stainless steel screws are recommended.

## Environment

A clean, smooth, flat, and strong surface is needed to install NewTechWood's products correctly. Please check with local building codes before ever installing any type of fencing. If installation does not occur immediately NewTechWood's products need to be put on a flat surface at all times. Never ever should it be put on a surface that is NOT flat.

## Planning

Plan a layout for your fencing before starting it to ensure the best possible looking fence for your project. Building codes and zoning ordinances generally apply to permanent structures, meaning anything that is anchored to the ground or attached to the house. So nearly every kind of fencing requires permits and inspections from a local building department. We recommend drawing out a site plan of your proposed project that you intend to do to minimize errors and make your perfect fence.

## Construction

NewTechWood UltraEasy Composite fence is NOT intended for use as support against a force, or other primary load-bearing members. NewTechWood must be supported by a code-compliant substructure. While NewTechWood products are great for retrofits, NewTechWood's products CANNOT be installed on existing siding boards.

## Static

Static can also be more prevalent in areas that are of higher altitude because the humidity is lower. For these areas, be careful of using conductive objects such as metal railing and chairs as static shocks might occur more often. A potential way to lower the amount of static shocks occurring is to apply Staticide ([www.aclstaticide.com](http://www.aclstaticide.com)) on your deck or use anti-static mats before doorways.

## Ventilation

UltraEasy Composite fence needs to have at least one of the clips or stopper installed at the bottom of each aluminum post sleeve as well as a starting and ending aluminum trim to work properly.


If one clip or stopper is not installed at the bottom of the post sleeve, there will be not sufficient enough air flow and could result in high wind speeds damaging the fence.

## Heat and Fire


Excessive heat on the surface of NewTechWood products from external sources such as but not limited to fire or reflection of focussing sunlight from some optical objects can potentially harm NewTechWood products. This extreme elevation of surface temperatures, which exceeds that of normal exposure, can possibly cause NewTechWood products to melt, sag, warp, discolor, increase expansion/contraction, and accelerate weathering.

# Framing Layout for the UltraEasy Fence


1. Straight Line




3. T-intersection




2. Right-Angle Corner














4. Cross-intersection



# Exploded View of UltraEasy Composite Fence



## Parts List

<u>Code</u>		<u>Qty</u>	<u>Description</u>
A		x12	Fence Board
B		x1	Aluminum Ending Trim
C		x1	Aluminum Starting Trim
D		x4	Galvanized Steel Tube "Option, not included as standard"
E		x2	Clip for Ending Trim
F		x2	Screw
G		x2	Stopper
H		x2	Screw
I		x2	Post Sleeve
J		x8	Post Trim
K		x2	Post Cap

### Please Note:

The shape of the accessories is different based on various fence board profiles. Refer to the concerned material list for the actual information.

# Installation Procedure

## Step 1: Post Installation


- Measure and Mark the location of the posts
- Digging the holes
- Setting the Posts

## Step 2: Fence Boards Installation

- Fix the Stopper
- Install the Starting Aluminum Trim
- Install the Fence Boards
- Install the Post Trims
- Install the Aluminum End Trim
- Install the Post Trim
- Install the Post Cap

## Step 1 Post Installation

- 1.1** Measure and mark the location of the posts at a distance of 5' (1.8m) on center of the posts, as shown in **Diagram 1.1**




**Diagram 1.1**



- 1.2** Dig the holes in **(650mm)** depth. It is about a third as deep as the post height. And the diameter of the holes should be **(240mm)**. It is about three times the width of the post, as shown in **Diagram 1.2**.


**Please Note:**

In colder climate regions, dig the holes below the frost line. You can get the frost line in your area online or contact your local building office.




**Diagram 1.2**

- 1.3** Layer (150mm) of gravel at the bottom of the hole for proper drainage, as shown in **Diagram 1.3**



**Diagram 1.3**

- 1.4** Position the **Post (I)** in the middle of the hole on top of the gravel. Ensure the post are plumb using a two-side post level. Set the post height at **(1900mm)**, off the ground, as shown in **Diagram 18**.




**Diagram 1.4**

- 1.5** Pour the concrete into the hole until it's (50mm) below the ground level, as shown in **Diagram 19**.


**Please Note:**

**Make sure to pour the concrete evenly around the post, and the hole fills completely.**



**Diagram 1.5**

- 1.6** Fill the top of the hole with soil once the concrete is set, as shown in **Diagram 20**.



**Diagram 1.6**

## Step 2 Fence Boards Installation

- 2.1** Insert a **Stopper (G)** into the bottom of the **Post (I)** and fix it with the **Screw (H)**, as shown in Diagram 2.1

Please Note:

Ensure the **Stopper (G)** is placed at the bottom of the **Post (I)** properly.




Diagram 2.1

- 2.2** Put the **Aluminum Starting Trim (C)** over the **Stopper (G)**, as shown in Diagram 2.2 and Detail 22-1.






Diagram 2.2




Detail 2.2-1

- 2.3** Insert a **Galvanized Steel Tube (D)** into the central hollow of the 3rd, 6th, 9th and 12th **Fence Board (A)**, as shown in **Diagram 2.3** and **Detail 23-1**.




**Diagram 2.3**




**Detail 23-1**

- 2.4** Put the first **Fence Board (A)** over the **Aluminum Starting Trim (C)**, as shown in **Diagram 2.4**.



**Diagram 2.4**

- 2.5** Complete the installation for the rest of the **Fence Boards (A)**, as shown in **Diagram 25**.



**Diagram 2.5**



- 2.6** Insert the **Post Trim (J)** into the **Post (I)**, as shown in Diagram 2.6.




Diagram 2.6

- 2.8** Put the **Aluminum Ending Trim (B)** over the last **Fence Board (A)**, as shown in Diagram 2.8 and Detail 28-1.




Diagram 2.8

- 2.7** Put the **Clip (E)** inside the **Aluminum Ending Trim (B)** and fix it with the **Screw (F)**, as shown in Diagram 2.7.






Diagram 2.7




Detail 2.8-1

- 2.9 Cut a small piece of **Post Trim (J)** and put it over the **Aluminum Ending Trim (B)** to cover the slot between the **Post (I)** top and the **Aluminum Ending Trim (B)**, as shown in **Diagram 29** and **Detail 29-1**.




**Diagram 2.9**




**Detail 2.9-1**

- 2.10** Put the **Post Cap (K)** on the top of the **Post (I)**, as shown in **Diagram 2.10**.



**Diagram 2.11**

- 2.11** **Diagram 2.11** presents the final appearance after complete the installation.




**Diagram 2.11**

# Thank You

For Your Purchase

We want you to be completely satisfied





# UltraEasy Composite Fence Installation Guide (Inground Installation)

v2 NL\_EN

©2025 Newtechwood Corporation

NewTechWood® is a registered trademark of Newtechwood Corporation.

To obtain a copy of the most current version of this installation guide, visit us online at [www.newtechwood.nl](http://www.newtechwood.nl)

